

# Heated Grip INSTALLATION GUIDE

## Check all components

Before starting installation please check to make sure the package includes all components



Controller - 1 PC




Clamp.Top - 1 PC




Clamp.Bot - 1 PC

Package


Accessories



Heat Grip - 1 PAIR



Connector Wire - 1 SET




Thumb Heater - 1 SET




AUX wire - 2 PCS

## Wiring Connect Guide

- \* We highly recommend installation be performed by a certified mechanic.
- \* Damage can occur due to the wrong installation or incorrect wiring connections.



## Installation



DISCLAIMER: DUE TO THE COMPLEXITY OF MODERN ATV/UTV'S THERE IS NO WARRANTY OF THIS ELECTRICAL PRODUCT ONCE IT HAS BEEN USED. THIS IS SOLD WITHOUT ANY EXPRESSED OR IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THE DEALER, DISTRIBUTOR, NOR MANUFACTURER SHALL BE HELD LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES. INCLUDING BUT NOT LIMITED TO DAMAGE, LOSS OF REVENUE, COST PURCHASED OR ANY OTHER INCIDENT CAUSED USE THE USE OR MISUSE OF THIS PRODUCT.


Turn page over for operation instructions.

# BRONCO®

ATV & UTV COMPONENTS

## Heated Grip Operation Instructions

### Initialization




#### When Connected with power:

4 function LED indicators at the controller bottom will be light up.  
5 level LED indicators will be off.

In this status, the controller has no output yet, but is ready for operation.

\*special function : push the "S" button before pushing ">>", This will allow the controller to recall the memory/status when last turned off.

### Basic Operation



#### When all 4 function LED indicators are lit up

When you push the ">>" button, it will level up 1 step.

The cycle is : 0 > 1 > 2 > 3 > 4 > 5 > 0 > 1 > 2 .....

#### When only 1 of the function LED indicators is lit up

The operation method is the same as above, but the heating level is only related to the function that is lit up.

### Advanced operation mode



#### Switching from 4 function to individual function control mode

Press the "S" button for 3 seconds and then release.

Next, push the "S" button once, the function will switch to the next one, for example :

GRIP > THUMB > AUX1 > AUX2 > GRIP > THUMB .....



#### Setting up the heating level for each function

Push the ">>" button, after setting the heating level in a given function. The level will be memorized even when you switch between functions.

In this mode, each function can be configured to different levels and heat independently.

\*To turn off a certain function(s), push ">>" until level reaches zero.



#### Switching to basic operation mode

Press the "S" button for 3 seconds and then release.

All 4 function LED will be lit up together.

(The heating level will inherit the the Grip's level)

All 4 functions have the same level output as shown on the level LEDs.